






CHARGEUR
Notice d'utilisation


TM3185-CHARGEUR/B

VUE ÉCLATÉE






N°			Qty	Ref
*	Chargeur frontal		1	26423
1	Fourche		1	12749
2	Pilier droit		1	12756
3	Pilier gauche		1	12755
4	Bague		4	11409
5	Bague		4	10379
6	Axe		2	11795
7	Axe		2	11796
8	Protection avant		1	13814
9	Axe		2	11808
10	Axe		4	11806
11	Axe		4	11911
12	Axe		2	13127
13	Goupille	R3	2	1570
14	Rondelle	16	6	1975
15	Rondelle	20	2	3898
16	Ecrou	M16/200	6	3012
17	Ecrou	M20/250	2	3013
18	Goupille	6 x 50	6	14419
19	Vis	M6/100 x 12	2	13125
20	Vis	M8/125 x 60	2	8922
21	Rondelle	6	2	2218
22	Pied de stationnement		2	13123
23	Pied de stationnement		2	13124
24	Vis	M12/175 x 70	2	1650
25	Vis	M12/175 x 25	2	13126
26	Ecrou	M12/175	4	7469
27	Passe paroi		2	14593
28	Autocollant		2	13210
29	Autocollant		2	13213
30	Autocollant		2	13214
31	Autocollant		1	15368
32	Autocollant		1	25446


*Pour chaque commande spécifier le numéro de serie



N°			Qty	Ref
33	Plug	1/4 ISO-B	4	13280
34	Adapteur	1/4 - 1/4	1	12260
35	Joint	1/4	18	1510
36	Vanne de fermeture		1	6750
37	Adapteur	1/4 - 14/150	20	3974
38	Flexible	14/150-1570-14/150	3	13103
39	Flexible	14/150-1470-14/150	1	14152
40	Bloc gauche		1	12515
41	Bloc droite		1	12516
42	Vis	M8/125 x 60	2	8922
43	Tube		4	13235
44	Flexible	1/4-920-14/150	2	13105
45	Flexible	1/4-610-14/150	2	13106
46	Adapteur	1/4 - 16/150	4	14089
47	Flexible	1/4-820-16/150	2	13227
48	Flexible	1/4-455-16/150	2	13107
49	Adapteur	1/4	8	7444



N°		Qty	Ref
50	Vérin d'élévation	2	24252
51	Vérin du bennage droit	1	24258
52	Vérin du bennage gauche	1	24259



Ref: 25951



ISEKI France S.A.S - ZAC des Ribes
27, avenue des frères Montgolfier - CS 20024
63178 Aubière Cedex
Tél. 04 73 91 93 51 - Fax. 04 73 90 23 11
E-mail : info@iseki.fr - www.iseki.fr